

# X7 (HARD CEILING CONCEALED FLANGE)

PARTS LIST	PART NO.	DESCRIPTION
FINISH PLATES:		
	91456	Flush
	91457	Regress 1
	91458	Regress 3
	91459	Wall to Wall (WTW)
0000	29513	Aligner Spline
	101504	Body Joiner
	101274	Reflector Removal Tool

PARTS LIST	PART NO.	DESCRIPTION
	82484	Lens Removal Tool
	_	Lens
	100639	Overhead Mounting Bracket
	100-00086-14	#6 x ¾″ Phil Pan Tek Screw
	100-00286-14	#6-32 x 3/16" Sheet Metal Screw
	100-00019-14	#8 x 1⁄4" HWH SMS Phil Screw
	100-00273-14	7⁄64″ x 1″ Aligner Pin




#### PRULITE.COM 213.746.0360

PRUDENTIAL LTG.


# X7 (HARD CEILING CONCEALED FLANGE)


#### **CEILING PREPARATION**


- 1. Cut ceiling opening to dimensions specified (see rough-in dimensions, below) and screw mounting brackets onto studs or ceiling joists (Figures 1 & 3).
- Remove LED reflector and install fixture housing onto mounting bracket or hanger bolt (shallow plenum).
- 3. Pull supply wires through K.O. into the fixture.
- 4. Place aperture guides inside fixture to prevent any deformation of housing (Figure 4) during installation. Screw flange onto ceiling. Drive screws straight up, DO NOT ANGLE, will distort aperture opening. Install lens to test for proper fit. If lens fits too tight or too loose,unscrew flanges from ceiling, adjust aperture opening accordingly and re-secure flange to ceiling. Test lens again, and repeat until lens snaps in firmly.
- 5. Apply plaster around flange (Figure 5).
- 6. Make all wire connections and replace LED reflectors. Snap lens into housing.



FOR JOINING AND REFLECTOR DETAILS SEE PAGE 4.











NOTE: Secure flange to ceiling with drywall screws (by others)

Test the lenses for proper install before mudding the fixture









WARNING: Ground fixture in accordance with local and national electrical codes. Failure to do so may result in serious personal injury.


if too loose, or break if too tight.







# PRUDENTIAL LTG.

# X7 (HARD CEILING CONCEALED FLANGE)



#### REFLECTOR DETAILS








#### PRIJLITE COM 213 746 0360


# FILLER KIT





# **INSTALLATION**


#### PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY:

1. Determine **FILLER** location & measure length of filler needed











#### 2. Disassemble **FILLER** Kit




#### 3. Measure Trim and Mark for Cutting






# FILLER KIT


## 4. Cut and discard Filler Housing




#### 5. Cut and discard reflector




#### 6. Drill and fix end plate




## 7. Join housings



8. Install filler



### 9. Install Reflectors



**NOTE:** Do not cut or remove any section of LED tray as it will cause uneven lights levels in the filler kit.

All sections of the LED tray should be rolled under the led reflector in the previous fixture housing.