X3 — HARD CEILING



PART	PART NO.		DESCRIPTION			
	-		Lens (SHIPPED INSTALLED)			
	19031		Mounting Strap (X3)			
PRU CABLE ASSEMBLY:						
j	100-00039-08	53″				
T A	100-00085-08	100″	Aircraft Cable			
	100-00042-08	200″				
	100-00262-14	3/4 WIRE	Metal Strain Relief Bushing			
	100-00264-14	5/6 WIRE				
	100-00319-14 100-00316-14	WHITE BLACK	Threaded Bushing			
	100-00310-14	WHITE				
	100-00321-14	BLACK	%" Universal Bushing			
	100-00284-14		½″ x 11/8″ IPT Brass Threaded Nipple			
	100-00239-14		½″ IP Knurled Nut			
	100-00228-14	3/4 WIRE	Plastic Strain Relief Bushing			
	100-00346-14	5/6 WIRE				
CANOPIES:						
\circ	28975		5½″Ø SPF Canopy (2 Hole)			
(°,0)	65392		5½″ Ø DPF Canopy (3 Hole)			
·	100-00006-08		5½″ Ø NPF Canopy (X3)			
	138571		Magnetic Flash Suppression Device (SHIPPED INSTALLED)			

FOR RPM/SPM MOUNTING, SEE SEPARATE INSTALLATION SPEC

18GA SJT	CORD:	3 WIRE 4 WIRE 5 WIRE 6 WIRE			
*	WHITE	100-00023-09	100-00024-09	100-00912-09	100-01002-09
1	WHITE 600v	100-00059-09	100-00060-09	100-00919-09	100-00604-09
	BLACK	100-00956-09	100-00025-09	100-00933-09	100-00317-09
1	BLACK 600v	100-00318-09	100-00606-09	100-00457-09	100-00607-09





X3 — HARD CEILING


GENERAL NOTES


- Depending upon ceiling construction, structural reinforcement required at mounting locations.
- Fixture dis-assembly not required for installation.
- Power cord provided in bulk and is to be cut to length and stripped by installer unless "PIF" is specified.

MOUNTING LOCATIONS










X3 — HARD CEILING



- 1. Install cable hardware on ceiling (see separate cable installation instructions).
- 2. Attach plastic strain relief bushing to end of power cord (figure 1).
- 3. Attach aircraft cables to housing by screwing the cable gripper into housing at mounting location.
- 4. Wire power cord to fixture wires protruding the back of fixture housing. For fixtures with internal EM drivers, **DO NOT** plug the connectors until after normal power has been applied to the fixture.
- 5. Secure power cord to housing by pushing cord into exposed hole until strain relief bushing snaps into place (figure 2).



WIRING:

0-10V (+): PURPLE	0-10V (-): GREY			
DALI (+): PURPLE	DALI (-): GREY			
EcoSystem DALI (+): PURPLE	EcoSystem DALI (-): GREY			
HOT: BI	LACK			
NEUTRAL: WHITE				
GROUND: GREEN				
CONSTANT HO	OT (EM): RED			



Hard Ceiling (X3) | CAX

Adjustable Cable Support

INSTALLATION INSTRUCTIONS


PRIJLITE COM 213 746 0360

INSTALLATION

- Anchor mounting straps to ceiling at cable locations. If mounting plan drawings is provided follow dimensions specified in row or pattern layout.
 (Contractor is to determine best anchoring hardware to be used in securing mounting strap to ceiling)
- 2. Insert non-crimped end of support cable through top threaded end of 1/4-20 coupling. Pull cable until crimp stops inside threaded end of coupling.
- 3. Push non-crimped end of cable through top (smooth end adjustable glider). Insert cable completely through glider. Glider will engage by pressing top smooth end down. Hold in place and pull back for adjustment.
- 4. Insert threaded barrel of adjustable glider through fixture. Securely attach glider to fixture with nutkeps lock (do not tighten with excessive force). Trim excess cable no less than 3" beyond cable outlet.
- 5. Unscrew threaded ring from top of ¼-20 coupling. Insert ¼-20 coupling through ⅓₂₂″ dia. center hole on canopy and let threaded ring and canopy rest on fixture end. Lift coupling/cable to ceiling with fixture attached and thread ¼-20 coupler onto strap bolt (be sure coupling is secure). Adjust cable to required distance from ceiling surface. Lift canopy against ceiling surface and secure in place with threaded ring.

NOTE: Depending on ceiling construction, reinforcement may be required at each mounting location.

CAUTION: Do not remove crimp from cable. Crimps are factory pressed onto cable for maximum strength. Prudential Lighting will not be responsible for damage or injuries which occur due to cable/crimp alterations. If different cable lengths are required, contact Prudential Lighting immediately.



a plaster ring. Refer to nec 370-16 for maximum electrical box fill.



Hard Ceiling (X3) | CAX

Adjustable Cord / Cable Support


INSTALLATION INSTRUCTIONS

PRIJLITE COM 213 746 0360

INSTALLATION

- 1. Use #8-32 \times 7%" screws (provided by others) to fasten the mounting strap to the J-box. If weight exceeds 50 pounds, reinforce mounting strap with support wire secured to structural material (support wire provided by others).
- 2. Insert non-crimped end of support cable through top threaded end of coupling. Pull cable until crimp stops inside threaded end of coupling, push non-crimped end of cable through top (smooth end of adjustable glider). Insert cable completely through glider. Glider will engage around cable to prevent slipping. Disengage glider by pressing top smooth end down. Hold in place and pull cable back for adjustment.
- 3. Insert threaded barrel of adjustable glider through fixture. Attach glider to fixture with lock washer and hex nut. (DO NOT TIGHTEN WITH EXCESSIVE FORCE) Trim excess cable no less than 3" beyond cable outlet.
- 4. Remove ½" round K.O. located on surface of fixture end. Contractor to field cut SJT cord at specified lengths and strip back a portion of outer insulation from one end of SJT cord (contractor to determine amount to be stripped). Insert stripped end of cord through snap bushing. Press snap bushing & cord into ½" round opening. Place metal strain relief bushing around cord under fixture end and crimp with pliers. Cord should be secured to fixture end. Insert top end of cord through universal bushing, and threaded bushing. Trim cord to required length and secure to canopy with strain relief through ½" nipple. Male all wire connection.
- 5. Unscrew threaded ring from top of ¼-20 coupling. Insert ¼-20 coupling through center hole on canopy. Apply small amount of thread lock on mounting stud. Lift coupling/canopy, and fixture to mounting strap and screw coupling to bolt (be sure coupling is secure). Adjust cable to required distance from ceiling surface.

CAUTION: Do not remove crimp from cable. Crimps are factory pressed onto cable for maximum strength. Prudential Lighting will not be responsible for damage or injuries which occur due to cable/crimp alterations. If different cable lengths are required, contact Prudential Lighting immediately.







PRULITE.COM 213.746.0360

- 1. Disconnect power from fixture (for an emergency disconnect the couple as well).
- 2. Remove the lens (figures 1).
- 3. Remove the LED Trays (figure 2).
- 4. Replace LED Tray and/or driver with new part.
- 5. Replace lens.
- 6. Power Fixture.

