
## MAINTENANCE INSTRUCTIONS


LED & DRIVER REPLACEMENT









## PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY:




Locate faulty LED Rail or Driver. Starting at nearest end of row, attached tape strips approx 4' beyond faulty equipment.




Remove end plate, magnet and end trim (when possible).



Use gloves provided. Gently lift bottom edge of reflector and remove from housing.



**USE GLOVES PROVIDED.** Pull reflector over entirety of housing row. Tighten roll to remove excess slack. Clamp roll to keep from unrolling.



Let reflector rest on tape strips

Remove sheet metal cover held on by screws to access wiring. Replace faulty equipment and reinstall all components in reverse order.

**WARNING:** Ground fixture in according with local and national electrical codes. Failure to do so may result in serious personal injury.