

## **P3900 / P4000** | Pendant & Surface




### INSTALLATION INSTRUCTIONS

### X3 SURFACE MOUNT

#### **INSTALLATION**

- Bolt pattern on back of fixtures are provided as ¼" knockouts and must be removed along with power access knockouts.
- Remove power access knockout on back side of fixture. Remove side reflector covering power access knockout.
- See fixture bolt hole pattern on page 2.
   Transfer bolt pattern onto ceiling surface measuring from center line out. Be sure adequate load bearing support is located at mounting screw locations.
- Attach ½" flexible conduit to power access hole and secure in place with lock nut. Make all wiring connections.



WARNING: Ground fixture in accordance with local and national electrical codes. Failure to do so may result in serious personal injury.





# **P3900 / P4000** | Pendant & Surface




### INSTALLATION INSTRUCTIONS

### X3 SURFACE MOUNT

- 5. Replace side reflector amd align fixture bolt holes with holes on ceiling surface.
- Secure fixture to ceiling surface with screws for adequate load support (minimum #12 screws)
- 7. Install lens.





**WARNING:** Ground fixture in accordance with local and national electrical codes. Failure to do so may result in serious personal injury.






# **P3900 / P4000** | Pendant & Surface



### INSTALLATION INSTRUCTIONS

### X3 SURFACE MOUNT



#### **ACCESS PLATE NOTE**

Removable access plate only provided with 1" ceiling standoff mounting option (not shown). For direct surface power feed use %" knockout within access plate knockout.

--ф-- 7⁄8″ KNOCKOUT

¼" MOUNTING KNOCKOUT

①①① TUNABLE WHITE KNOCKOUT

ACCESS PLATE KNOCKOUT

(WITH 1/6" KNOCKOUT)

WARNING: Ground fixture in accordance with local and national electrical codes. Failure to do so may result in serious personal injury.

